Table Of Contents

SECTION 1: INTRODUCTION
1. Introduction 1-1

SECTION 2: SPECIFICATIONS
1. Specifications 2-1

SECTION 3: MACHINE OVERVIEW
1. Top View 3-1
2. Power Supply 3-2
3. Machine Interface 3-3
4. Start-Photocell Bracket 3-3
5. Register Board 3-4
6. Numbering Heads 3-5
7. Regulator Assembly 3-6
8. Quality Control Sheet 3-8

SECTION 4: OPERATING KEYBOARD
1. Overview 4-1
2. Idle Mode 4-2
3. Run Mode 4-3
4. Stopping a Job 4-4
5. Changing Programs 4-4
6. Programming a Job 4-5
7. Motor Speed Control 4-6

SECTION 5: SETUP PROCEDURES
1. Perforating/Slitting/Scoring 5-1
2. Idler Wheels 5-3
3. Main Rollers 5-3
4. Ink Pads 5-4
5. Setting the Starting Number 5-5
6. Repeat Selector 5-5
7. Locating the Numbering Heads 5-6
8. Impression Strength 5-6
7. Flatness of Impression 5-7
8. Stripper Assemblies 5-8

SECTION 6: MAINTENANCE
1. Numbering Heads 6-1
2. Photocells 6-2
3. Lubrication 6-2

SECTION 7: TROUBLESHOOTING

1. Numbering Heads 7-1
2. Print Quality 7-2
3. Registration 7-2
4. Error Messages 7-3
5. Errors at Power Up 7-4
6. Errors Encountered When Running Programs 7-5
7. LED Indicators 7-6
8. Self-Diagnostic Features 7-9

SECTION 8: TEST MODES

1. Test Modes 8-1

SECTION 9: PARTS LIST

1. Top View 9-1
2. Non-Operator Side 9-2
3. Structural Parts 9-3
4. Electrical System 9-4
5. Parts List 9-5